

G-Body head unit relocate kit

This kit is shipped loose assembled so you will have an idea how assembly goes. Please read all instructions before installing.

1. Disconnect the vehicle's battery.
2. Remove the plastic dash bezel. Unplug the wiring to the cigarette lighter. Remove the cigarette lighter from the bezel by unscrewing the back housing from the contact canister (part on front of bezel that houses the lighter)
3. Remove the head unit from the vehicle. Unbolt the heat/AC (HVAC) controls. Do not disconnect anything from the heat/AC controls. This install can be done without removing the HVAC controls from the vehicle, or any of the wiring and hoses to the controls.
4. You must now remove the dash material in the upper right hand corner of the dash cavity. This can be simply done with a small hand saw.



5. Press the cigarette lighter plug through the backside of the mounting bracket. This plug should pass through the hole on the lower right side of the bracket.
6. Place the mounting bracket into the dash cavity and over the heater controls. Gently maneuver the HVAC controls into place on the install bracket, but do not bolt them in at this time.
7. Install the head unit to the mounting bracket. This can be done using the “sleeve” your aftermarket head unit came with, or you may choose to ISO install. Two spacers are provided and must be installed if you choose this type of install. Due to the differences in head units, you must provide your own screws to secure your head unit to the mounting bracket. **YOU MUST FIGURE HOW LONG AND WHAT SIZE OF BOLTS TO USE FOR THIS! TOO LONG OF BOLTS CAN DAMAGE YOUR HEAD UNIT. I TAKE NO RESPONSIBILITY FOR YOUR ERRORS!!**
8. Once the head unit is secured to the mounting bracket, connect all wiring to the head unit.
9. Install the mounting plate by bolting it to the sides of the dash cavity. You will reuse the vehicles screws for this, installing them in the factory locations. There should be 4 screws on the driver’s side, and two screws on the lower right side of the passenger side.
10. Install the HVAC controls to the mounting bracket. Use the 4 short screws and washers provided in the kit for this.
11. Install the cigarette contact canister and back housing onto the face plate included with the kit.
12. Plug the cigarette lighter into the wiring harness and install the face plate.
13. Use the 4 flat head Allen head screws provided in the kit to secure the face plate to the mounting bracket. Tighten all four screws evenly and snugly. Do not over tighten!

The two parts taped together are spacers for ISO installation. When doing this install, it may be necessary to use more shims in addition to the two I include if you have a fold out head unit. You do not want the kit or the head unit to flex or pull together when tightening. This adds stress to the motor and track that opens and closes the head unit. You can use small pieces of steel or plastic banding sandwiched in-between the spacer and the install bracket, it works great.

If you have any questions feel free to contact me at
Anderson@TheDetailSS.com

If this item was purchased from an [E-bay](#) auction please note: I will gladly leave you positive feedback **AFTER** feedback is received for me so I know you are completely satisfied with your purchase.

Thank you for your business,
Sean Anderson